WALL

BACKSPLASH

2.000

TEMPLATE OUTLINE

R.063 (2) PLACES

15.540

25.250

INSTRUCTIONS FOR COUTERTOP INSTALLATION OF MIDMARK M250 ULTRASONIC CLEANER

0:1. CHECK THAT THE MODEL NUMBER OF THE TEMPLATE AND THE MODEL NUMBER OF THE MIDMARK ULTRASONIC CLEANER ARE THE SAME.
2. PLACE THE TEMPLATE ON THE COUNTERTOP AS SHOWN AT THE DESIRED LOCATION
3. CHECK UNDER THE COUNTER TO ASSURE THAT THE AREA IS CLEAR OF OBSTRUCTIONS AND THAT THERE IS SUFFICIENT CLEARANCE TO MAKE THE ELECTRICAL AND DRAIN CONNECTIONS.
4. CUT OUT THE TEMPLATE AND THE INSTRUCTION PANEL. THIS WILL FORM A SQUARE FRAME WITH A SQUARE OPENING.
5. TAPE THE TEMPLATE TO THE COUNTERTOP USING MASKING TAPE ALONG BOTH THE INSIDE AND OUTSIDE OF THE SQUARE OPENING.
6. DRILL 12 1/2 INCH DIAMETER HOLES IN THE SPECIFIED LOCATIONS.
7. PLACE MASKING TAPE ON THE BOTTOM OF A SABER SAW TO PROTECT THE COUNTERTOP FROM POSSIBLE SCRATCHES.
8. INSTALL A SMOOTH CUT WOOD BLADE (32 TEETH/INCH) INTO A SABER SAW AND CUT ALONG THE CENTER OF THE TEMPLATE OUTLINE. FOLLOW THE TEMPLATE OUTLINE ALL AROUND UNTIL THE INSIDE PANEL FALLS FREE.
9. CHECK THE OPENING FOR AREAS THAT EXTEND BEYOUND THE OUTLINE AND REMOVE THEM BY FILING OR SANDING.
10. TEST THE FIT OF THE ULTRASONIC CLEANER AND MARK THE AREAS THAT BIND.
11. FILE OR SAND AWAY THE HIGH SPOTS UNTIL THE UNIT FLANGE CONTACTS THE COUNTERTOP ALL AROUND.
12. REMOVE THE MIDMARK ULTRASONIC CLEANER.
13. SEAL THE NEWLY CUT EDGES OF THE CUTOUT WITH OUTDOOR GRADE PAINT OR URETHANE COATING. ALLOW TO DRY ACCORDING TO THE MANUFACTURERS INSTRUCTIONS ON THE CONTAINER.
CAUTION: FAILURE TO SEAL THE RAW CUT EDGES OF THE COUNTERTOP CAN RESULT IN DELAMINATION AND SWELLING OF THE BASE MATERIAL.
14. INSTALL THE MIDMARK ULTRASONIC CLEANER AND MAKE THE REQUIRED ELECTRICAL AND DRAIN CONNECTIONS.
15. TEST THE UNIT AND MAKE SURE THAT EVERYTHING IS FUNCTIONING CORRECTLY.
16. USING A CLEAR SILICONE CAULKING, FORM A BEAD ALL AROUND THE PERIMETER WHERE THE UNIT MEETS THE COUNTERTOP.
17. ALLOW THE SILICONE TO FULLY CURE ACCORDING TO THE MANUFACTURERS INSTRUCTIONS ON THE CONTAINER.
CAUTION: TURNING THE MIDMARK ULTRASONIC CLEANER ON BEFORE THE SILICONE CAULK HAS CURED CAN RESULT IN A BREAKAGE OF THE WATER-TIGHT SEAL BETWEEN THE COUNTERTOP AND THE MIDMARK ULTRASONIC CLEANER.

R.250 (3) PLACES

DRILL 12 1/2 INCH DIAMTER HOLES AS MARKED

R.188

FRONT

R.250 (12) PLACES

PT. NO. 003-1221-0X

AS REQUIRED

15.213

MA579700i